Trace Explosive Detection Challenges for Transportation Security

HSARPA Workshop

April 6, 2004

Presented by: Dr. Susan Fowler Hallowell

Director of Technology, Transportation Security Lab



Transportation Security Administration

Transportation Security Laboratory

William J. Hughes Technical Center Atlantic City International Airport

NJ 08405



Department of Homeland Security DHS

Border & Transportation Security (BTS)

Transportation
Security Administration
(TSA)

National Transportation System Security Plan

Rail

Maritime

Transit

Pipeline

Aviation

Highway



Security Challenge

Mission

The Office of Security Technology will develop and implement the best security technology solutions to protect the nation's transportation systems, ensuring freedom of movement for people and commerce.

Transportation Systems

Aviation Pipeline

HighwayRailway

Maritime Transit



Domain Awareness

What are we trying to protect?

- People
- Cargo (checked and carry-on baggage and commercial shipments)
- Conveyance
- Facilities

What are we trying to protect against?

- Explosives Radiological/Nuclear
- Weapons
- Unauthorized Access
- Chemical/Biological/Agents



Technology Requirements

- Very Low False Alarm Rate
- Very High Probability of Detection
- Integrated Element, Holistic Security Infrastructure
- Minimal Decision Making by Human
- Automated
- Robust
- Can Be Operated by Screeners
- Not Too Expensive
- Privacy Concerns Addressed



Where we are:

Equipment Deployment

ATSA Requirement: All checked bags must be screened by Explosive Detection Systems (EDS) or EDS-equivalent by December 31, 2002

- Deployed the following to airports throughout the country:
 - 1733 Enhanced Walk Through Metal Detectors (EWTMD)
 - 1392 Threat Image Projection (TIP) ready X-ray machines
 - 1161 Explosive Detection Systems (EDS)
 - 6595 Explosive Trace Detection (ETD) Units



Enabling Technologies

- Access Control
- Communications
- Bulk (Explosive) Detection
- Trace (Explosive) Detection
- Human Factors
- Aircraft or Conveyance Hardening



Explosives and Weapons Detection 'Bulk and Trace' Programs



 \leftarrow Bulk \rightarrow






← Trace →






Trace Detection ←










C-4 particle on cloth at

Trace Program:

- Explosives
- Chemical Agents
- Biological Agents







Vapor molecule of TNT April 6, 2004

EXPLOSIVE TRACE DETECTORS

- Can detect & identify microscopic amounts of explosive material
- Used for detection of the explosive component of an IED
- Used in conjunction with X-Ray and physical search to provide an additional layer of security
- ETD alarm does not necessarily mean there is an IED in the bag
 - Passenger carrying certain medications
 - Fertilizers/high nitrogen levels



Deployed Trace Detectors

BARRINGER

- Technology Ion Mobility Spectrometry
- Approved models IonScan Models 400 and 400B

IONTRACK

- Technology Ion Mobility Spectrometry
- Approved models Itemizer-DOS & Itemizer-W

THERMODETECTION

- Technology GC/Chemiluminescense
- Approved models EGIS Models 3000 & II





TOX





Trace Detection

- Why do Trace Detection
- What are we detecting
- Where are the Traces
- How do you collect them
- What Next???



Why do Trace

- Only way to screen people for explosives
- Available sample is independent of the size of the bomb (good and bad news)
- Instruments are inexpensive and safe
- Nuisance alarm rate is low
- There will always be a sample ???



Trace Detection

- Collect
- Separate
- Detect
- Residues or vapors of explosives
- Optically View or Activate Traces



What have we learned?

- Nuisance alarms
 - Manageable
 - Reproducible
 - Resolvable
- Operationally Viable



Trace Explosive Detection

- Ion Mobility Spectrometry
- ChemiluminesenceMass Spectrometry
- Canine OlfactionAntibodiesOptical Techniques



Not Changed since last ICAO Workshop

- Sampling techniques
 - Inefficient
 - Ineffective
- Detection Technology



What are we Detecting?

Fortuitous Contamination
Or

Reliable Indications

Policy makers are concerned



Where are the traces?

About where you would expect them to be.



How do you collect them?

The unsolved problem -

- Rubbing
- Wiping
- Air Flow
- Optical detect in place



Explosives

Standard Explosives

- ❖ TNT
- RDX
- PETN
- Nitroglycerin (NG)
- Ethylene Glycol Dinitrate (EGDN)

Plastic Explosives

- ❖ C-4 (RDX)
- Detasheet (PETN)
- Semtex (RDX + PETN)

Improvised Explosives

- ANFO (Ammonium nitrate + fuel oil)
- Urea nitrate
- Triacetone triperoxide (TATP)



Explosive Compounds


$$H_2C$$
 CH_2
 NO_2
 CH_2
 NO_2
 RDX

$$O_2N-O-H_2C$$
 CH_2-O-NO_2 O_2N-O-H_2C CH_2-O-NO_2 PETN


$$NO_2$$
 NO_2
 NO_2
 NO_2
 NO_2
 NO_2

$$NO_2$$
 NO_2
 NO_2
 NO_2
 NO_2
 NO_2
 NO_2
 NO_2
 NO_2

$$NO_2$$
 H_2C
 CH_2
 NO_2
 H_2C
 CH_2
 NO_2
 H_2C
 CH_2
 NO_2
 NO_2
 NO_2
 NO_2
 NO_2



Triacetone triperoxide






Name	Common Name	Molecular Weight
Nitroglycerine	NG	227
Pentaerythritol tetranitrate	PETN	316
Nitrocellulose (structural unit)		324 +%N
Hexogen	RDX	222
Octogen	HMX	296
Trinitrotoluene	TNT	227
1,3,5-triamino-2,4,6- trinitrobenzene	ТАТВ	258



Ref: US DOE Study






Tagging of Explosives

The International Civil Aviation Organization (ICAO) has mandated that volatile taggants be added to plastic explosives during their manufacture, in order to facilitate the detection of these explosives. Four taggants were recommended:

Taggant	State (at 25° C)	Vapor pressure at 25º C [torr]
EGDN	liquid	0.006
DMNB	solid	1.67x10 ⁻³
o-MNT	liquid	0.11
p-MNT	solid	0.03

ION MOBILITY SPECTROSCOPY

(IMS)



- Substrate heated to vaporize particles
- •Molecules are ionized by a weak radioactive source and drift through a weak electric field
- •Particle time of flight is a distinct fingerprint, enabling detection

Applications:

- •Explosives detection on both luggage and people
- Detection of narcotics
- Detection of narcotics


Technical Barriers:

- •Dependent on screener sampling
- •Susceptible to atmospheric changes
- Calibration requirements
- Saturation possible





RDX Response Curve





Explosives Detection Methods People

- Emerging Technologies
 - Explosives Screening of passengers using trace portals
 - Imaging Technologies








Walk through trace explosives detection portal

The science and engineering behind the EntryScan.

The Science ...

- Aerodynamic Sample Collection
- Trace Detection / Identification

The ITMS Detector




–A New Hypothesis

Reynolds Averaged Navier-Stokes

$$\frac{\partial U_i}{\partial x_i} = 0$$

$$\frac{\partial U_i}{\partial t} + U_j \frac{\partial U_i}{\partial x_j} = -\frac{\partial \hat{p}}{\partial x_i} + \frac{1}{Re} \frac{\partial^2 U_i}{\partial x_j \partial x_j} - \frac{\partial}{\partial x_j} \frac{\overline{u_i u_j}}{\overline{u_i u_j}} + \delta_{i3} \frac{Gr}{Re^2} \Theta$$


Scalar Flow Model



Human Convection Plume



Laser Sheet Flow Visualization



What analyte is a detection dog signaling on?





Research and Development

R&D Efforts

- Determine detection odor signatures
- Determine canine "detection limits"
- Development of simulants and training aids
- Generalization to Other Explosives
 - Single Odor or "Bouquet"
- Dog Selection/Breeding
- Impact of Cross-Contamination
- Field Test Kit "Push-to-Test"
 Susan Hallowel



Partnerships

- TSWG
- Office of Special Technology
- U.S. Secret Service
- DARPA
- DoD Military Working Dog Program
- UK
- ONDCP
- Bureau of Alcohol Tobacco & Firearms (BATF)




Semtex H Ingredients

• Ingredients:

- 35% +/- 3% PETN
- 50% +/- 3% RDX
- 15% +/- 2% Butadiene-styrene + oil
- 0.1% minimum DMNB



Semtex H Headspace Analysis



Vapor Pressures at 25°C (Semtex H)

Headspace Components

- Ethylbenzene ~ 9.6 torr
- m-Xylene ~ 8.5 torr
- Styrene ~ 6.1 torr
- Nonane ~ 4.3 torr
- α -pinene ~ 4.4 torr
- Decane ~ 1.3 torr
- Ethyl hexanol $\sim 1.4 \times 10^{-1}$ torr
- Undecane $\sim 3.9 \times 10^{-1} \text{ torr}$
- Dodecane $\sim 1.2 \times 10^{-1} \text{ torr}$

Energetic Components

- PETN ~ 1.4 x 10⁻⁸ torr
- RDX ~ $2.6 \times 10^{-9} \text{ torr}$
- DMNB $\sim 2.0 \times 10^{-3} \text{ torr}$



TNT Headpace Major Constituents and Abundance

```
2,4-dinitrotoluene = 62\% (v.p. ~ 2.3 \times 10^{-4} torr)
1,3-dinitrobenzene = 16\% (v.p. ~ 3.9 \times 10^{-3} torr)
3,5-dinitrotoluene = 10\% (v.p. ~ 1.5 \times 10^{-4} torr)
1,4-dinitrobenzene = 6\%
trinitrotoluene = 3\% (v.p. ~ 5.9 \times 10^{-4} torr)
1,2-dinitrobenzene = 2\%
```



IBDS, Auburn University

Substance Sensitivities

NG, Cyclohexanone, DMNB

Detection Odor Signatures

 NG Smokeless Powder, C4, AN Dynamite, TNT, ANFO

Generalization



Major Constituents and Abundance of Targets

NG Smokeless Powder

- acetone = 81%
- toluene = 12%
- nitroglycerine = 7%
- limonene = < 1%

C4

- cyclohexanone = 76%
- toluene = 7%
- 2-ethyl-1-hexanol = 5%

TNT


- 2,4-dinitrotoluene = 62%
- 1,3-dinitrobenzene = 16%
- 3,5-dinitrotoluene = 10%
- 1,4-dinitrotoluene = 6%
- trinitrotoluene = 3%
- 1,2-dinitrobenzene = 2%

AN Dynamite

- ethylene glycol dinitrate
- ammonium nitrate




Olfactometer (vapor generator)





Olfactory Sensitivity





TNT Signature Response Summary

	Dogs					
Constituent(s)	6241	6561	6783	7819	7001	
2,4 DNT	X	X	X	X		
1,3 DNB	X			X		
DNT/DNB	X			X		



Signature Response Summary

•	TNT			Dogs	Dogs			
	Constituent(s)	6241	6561	6783	7819	7001		
	2,4 DNT	X	X	X	X			
	1,3 DNB	X			X			
	DNT/DNB	X			X			

C4
Constituent(s) 5174 6548 7007 6382
Cyclohexanone X X
2-ethyl-1-hexanol X X



Signature Response Summary

Dynamite Dogs
 Constituent(s)
 5174
 6548
 6382
 7007

 EGDN X
 Ammonium Nitrate X
 EGDN/Ammonium Nitrate X

Smokeless Powder (Hercules Unique)

	Dogs			
Constituent(s)		5174	7007	6382
Acetone		X	X	
Limonene			X	
Acetone/Limonene			X	
Acetone/Toluene/Limo Transportation Security	nene	X	X	X
Transportation Security Susan H		Hallowell	April 6, 200)4

Conclusions

- Signature is often multi-component, most volatile components of explosive
- Detection thresholds
 - DMNB ~ 0.550 ppb
 - others ~10 ppb
- different dogs cue on different things
- concentration is always a factor in training dogs
- Dogs, some better than others, can generalize odors



Acknowledgements

- Virginia Polytechnic Institute and Galaxy Scientific Corporation
 - Semtex H headspace data
- Aerodyne Research
 - Vapor Pressure Data
- Auburn University
 - TNT headspace and canine data



Explosive Trace Detectors The Future ...



Miniaturized Explosives Detection Systems



Explosives/Chemical Detection Systems


Present



Trace Portal ~ \$120k




Near-Term 2-3 Year




Portable
Raman uProbe
~ \$25k

Future ~ 5yr.+



MEMS Array Sensor < \$1k

Electronic Noses The desired solution






Obstacles to Overcome

- Minute quantities of explosive available
- Different types of explosives
- Vapors of volatile explosives or typical ingredients
- Vapors condensed on dust
- Particulates bound to surfaces
- Collect particulates efficiently and move to detector







Future Prospects

- Microsensors/electronic noses will replace existing vapor & trace detectors (IMS, TEA, MS).
- Nanotechnology will become the major technology of microsensors.



Questions?

